

M-CLEAN

Premium All Purpose Maintenance & Floor Cleaner

Performance Benefits

- **100% biodegradable**
- **Safe alternative to harsh caustic & toxic solvents**
- **Pleasant citrus odor**
- **Cost Effective – highly concentrated allowing for economical dilutions**
- **Versatility – universal cleaner & degreaser for a wide range of soils**
- **Non-butyl cleaner**
- **Non-flammable**

M-CLEAN is a powerful natural citrus floor cleaner and degreaser. The superior performance of this water based cleaner is derived from a synergistic blend of natural orange solvent and a unique surfactant system. This versatile product can be used for most industrial and commercial cleaning jobs. The product will remove heavy grease and oil deposits and deodorizes as it cleans. **M-CLEAN** is designed for use in automatic floor scrubbers, mop buckets, spray bottles, and hand cleaning applications.

Typical Characteristics

Appearance of Concentrate.....	Bright Orange
Odor	Citrus
Flash Point.....	None
Specific Gravity.....	1.017-1.037
pH of Concentrate.....	<12.5
Nitrites, Phosphates.....	None
Silicates.....	Yes

Recommended Application

M-CLEAN is recommended for use in automatic floor scrubbers at concentrations between 1 – 5%, depending on soil load. It is also recommended for use in manual cleaning operations at concentration rates between 5 – 10 %, depending on soil load. **M-CLEAN** can be used on a wide range of applications:

Equipment	Garages	Motors	Schools
Factories	Kitchens	Offices	Tools
Floors	Machinery	Restaurants	Walls